

# mazon

HEADBOARD FREE STANDING  
HEADBOARD BRACKET MANUAL

Instruction and User Guide

PLEASE READ OUR USER GUIDE  
CAREFULLY BEFORE USE

# HOW TO ATTACH A FREE STANDING HEADBOARD BRACKET

All Mazon bases come standard with 63mm headboard bolts.

All Mazon Headboards come standard with headboard slots, unless wall mounted is specified.

IDENTIFY EACH PIECE:



X2 FREE  
STANDING  
HEADBOARD  
BRACKETS



X4  
HEADBOARD  
D BOLTS



X1 BUTTON  
GLIDE FOR  
LEVELING



1. Place your headboard on the freestanding brackets.

2. Screw in the headboard bolts.

3. (If required) Screw in button glide to the freestanding bracket for leveling.



